

## General Safety

All power tools can be dangerous if both general and tool specific safety instructions are not followed carefully. General safety instructions apply to all power tools, both corded and cordless.

### Start with a Safe Work Area

- Keep your work area clean and well lit. Cluttered benches and dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, near flammable liquids, gases, or dust. Power tools create sparks, which may ignite such dust or fumes.
- Keep bystanders, children, and visitors away when using a power tool. Distractions can cause you to lose control.

### Electricity can be Dangerous

Grounded tools (three pronged cords) must be plugged into a properly installed and grounded outlet. Never remove or cut off the grounding prong or modify the plug in any way. Do not use any adapter plugs.

- Double Insulated tools have a polarized plug (one blade is wider than the other). This plug will fit into an outlet only one way. Do not change the plug in any way.
- Do not use AC only rated tools with a DC power supply.
- Store battery packs away from other metal objects like paper clips, coins, keys, nails, screws, or other small metal objects. These items can make a connection from one terminal to the other, shorting the battery terminals together and causing burns or fire.
- When using a power tool, don't touch grounded surfaces such as pipes, radiators, ranges and refrigerators. There is a higher risk of electric shock if your body is grounded.
- In damp locations, only plug your tool into a Ground Fault Circuit Interrupter (GFCI). If the work area does not have a permanent GFCI on the outlet, use a plug-in GFCI. Wear rubber gloves and footwear.
- Do not expose, use, or leave power tools in the rain or wet conditions.
- Do not abuse the cord, carry the tool by its cord, or pull the cord to unplug it. Keep the cord away from heat, oil, sharp edges or moving parts.
- Replace damaged cords immediately.
- Always hold the tool by the insulated gripping surfaces. Contact with hidden wiring or its own cord will make exposed metal parts of the tool "live" and shock the operator.

### Rules about Extension Cords

- When using a power tool outside, use an extension cord marked for outdoor use with "W-A" or "W". These cords are made for outdoor use.
- Extension cords with 3-prong grounding plugs must be plugged into 3-prong outlets when using grounded tools.
- Replace damaged or worn cords immediately.

### AMPS

The wire gauge and length of the extension cord must be able to handle the amps of the tool. Find the Amps (A) on the tool's nameplate and use the chart to determine the necessary wire gauge for your extension cord length.

**RECOMMENDED SIZES OF EXTENSION CORDS**

Tool Ampere Rating	120-volt AC Tools			
	Cord Length in Feet		Cord Size in AWG	
	25	50	100	150
3-6	18	16	16	14
6-8	18	16	14	12
8-10	18	16	14	12
10-12	16	16	14	12
12-16	14	12	N/A	N/A

## Good Personal Safety is a Must

Following good safety practices when using all power tools is a must. Make a habit of including safety in all of your activities.

- Always read and understand the tool's operator's manual, tool markings and the instructions packaged with the accessory before starting any work.
- Use safety equipment. Always wear eye protection. A dust mask, non-skid safety shoes, hard hat, or hearing protection must be used when needed. The reference to "safety goggles" or "safety glasses" in product specific sections provides potential options - always refer to the tool's operator's manual for the specific eye protection recommended, which should be marked as complying with current national standards.
- Stay alert, watch what you are doing and use common sense when using a power tool.
- Do not use tools when you are tired or under the influence of drugs, alcohol, or medication.
- Dress right. Do not wear loose clothes or jewelry. Contain long hair. Loose clothes, gloves, or long hair can be caught in moving parts. Be sure the power tool's switch is OFF before plugging it in or inserting a battery pack.
- Do not carry tools with your finger on the switch.
- Remove adjusting keys and wrenches before turning the tool ON.
- Always keep a firm footing when using power tools. Be sure you have balance and control before you start the job.
- Unplug tool/remove battery before changing accessories.
- Keep hands away from rotating or moving parts.
- Keep handles dry, clean and free from oil and grease.

## Do the Job Safely

- Use the power tool accessories only for the jobs for which they were designed.
- Secure and support the workpiece. Use clamps and a stable work surface. Do not hold the work by hand or against your body.
- Keep guards in place and functioning properly.
- Do not force the tool. Use the right tool for your job. It will do the job better and safer.
- Use only accessories recommended by the tool manufacturer. Accessories that may be suitable for one tool may become hazardous when used on another tool.
- Disconnect the plug from the power source or remove the battery before making any adjustments, changing accessories, or storing the tool.
- Do not touch the drill bit, blade, cutter or the workpiece immediately after operation; they may be very hot and may burn you.
- If a method of dust collection is available with the power tool, it should be used to reduce the risk of dust-related hazards.

## Maintenance Keeps Tools Working Safely and

- Do not use a tool if the switch does not turn it on and off. It must be repaired.
- Look at the tool before using it. Are moving parts misaligned or binding? Is anything broken?
- Damaged tools must be repaired before using them. Develop a maintenance schedule for your tool.
- Maintain accessories carefully. Keep blades and

bits sharp and clean.

- Take your tool to be serviced by qualified repair people. Service or maintenance performed by unqualified personnel could result in a risk of injury. For example: internal wires may be misplaced or pinched, safety guard return springs may be improperly mounted.
- When servicing a tool, use only identical replacement parts. Follow instructions regarding maintenance in the tool's operator's manual. Use of unauthorized parts or failure to follow the maintenance instructions may create a risk of electric shock or injury.
- Clean and lubricate a tool only as directed in its operator's manuals. Certain cleaning agents such as gasoline, carbon tetrachloride, ammonia, etc. may damage plastic parts.
- Maintain labels and nameplates. These carry important information. If unreadable or missing, contact the manufacturer for a replacement.

### **When Done, Store the Tools out of Harm's Way**

- To avoid accidental starting, unplug the cord, remove batteries and lock off the switch when the tool is not being used, when changing accessories, and when adjusting or cleaning tools.
- Keep tools out of reach of children and people unfamiliar with the tools.